


## "Relied on Worldwide in the Most Extreme Conditions"

## Steps to link Ensentic Controller to Weather Underground

- 1. Go to WeatherUnderground.com
- 2. Create an account
- 3. Click on "My Profile" and then click on "My Weather Stations" from the dropdown
- 4. Click on "Add a New PWS"



- 5. Follow the instructions the website provides to set up the weather station
- 6. Provide Texas Electronics with you "Station ID" and "Station Key" during the checkout process or send it to us via email. We will link your Weather Underground account to the backend of our software before the unit ships.



If the Weather Underground information is not provided at checkout it can always be added later by a quick call to Texas Electronics. You will need to have your "Station ID", "Station Key", and access to the weather station.